Daiwa

How to keep of refrigeration equipment

good condition during long-term closing

In order to use the device hygienically, please confirm the following contents when stopping the device for a long period of time.

Freezer & Refrigerator







②Clean it and wipe off all the water.



(3)Open the door and dry the inside of the cabinet to prevent mold and odors.



①Please take out all the food etc. in the refrigerator



④If the refrigerator has a power supply, be sure to disconnect the power supply after turning the power off.

«It is dangerous to turn off the power to the heater etc. with the outlet plugged in.

Ice Maker





①Close the water supply valve on the ice maker



③After about 30 seconds, the ice making mechanism will descend.

Before descending



2 Press the reset switch



④After descending, turn off the earth leakage breaker, disconnect the power plug, open the door, and dry the inside of the refrigerator.

