

Maintenance points and methods when reusing refrigeration equipment

In order to use the equipment hygienically, please confirm the following contents for the procedure to restart the operation of the equipment that has been stopped for a long time.

Freezer & Refrigerator



① For hygienic use, open the door and blow air into the storage for a while.



② Just in case, clean the inside of the cabinet again



③ Firmly insert the plug of the power cord on the back of the main unit into the dedicated outlet. (Please turn on the equipment with the earth leakage breaker)



④ After displaying the internal temperature, the fan motor and compressor start operating.

⑤ After the inside has cooled sufficiently (After operating for about 2 hours) please put the goods.

Ice Maker



① For hygienic use, open the door and blow air into the storage for a while.



② Just in case, clean the inside of the cabinet again (In particular, stock, packing etc.)



③ Open the water supply valve on the ice maker (Check if there is no water leak)



④ Firmly insert the plug of the power cord on the back of the main unit into the dedicated outlet. (Please turn on the equipment with the earth leakage breaker)



⑤ Ice usually forms within 1 hour after the equipment starts operating, but discard the first ice and use it again from the next ice making.